



TABELLA PASSI

PASSO

Ø mm.	CHIAVE	MA	MB	WITH.	Ø mm.	SPIRE
	DADO / VITE	P. Grosso	P. fine			
3	5,5	0,5	0,35	1/8	3,17	40
3,5	7	0,6	0,35			
4	7	0,7	0,5	5/32	3,97	32
4,5	8	0,75	0,5			
5	8	0,8	0,5	3/16	4,76	24
6	10	1	0,75	1/4	6,35	20
7	11	1	0,75			
8	13	1,25	1	5/16	7,94	18
9	14	1,25	1			
10	17	1,5	1,25 (1)	3/8	9,52	16
11	19			7/16	11,11	14
12	19	1,75	1,25 (1,5)	1/2	12,70	12
14	22	2	1,5	9/16	14,29	12
16	24	2	1,5	5/8	15,87	11
18	27	2,5	1,5			
20	30	2,5	1,5			
22	32	2,5	1,5	3/4	19,05	10
24	36	3	2	7/8	22,22	9
27	41	3	2	1" CH 41	25,40	8
30	46	3,5	2	1" 1/8	28,57	7
33	50	3,5	2	1" 1/4	31,75	7
36	55	4	3	1" 3/8	34,92	6
39	60	4	3	1" 1/2	38,10	6
42	65	4,5	3	1" 5/8	41,27	5
45	70	4,5	3	1" 3/4	44,45	5
48	75	5	3	1" 7/8	47,62	4,5
52	80	5	3	2"	50,80	4,5
56	85	5,5	4			
60	90	5,5	4			
64	95	6	4			
68	100	6	4			
72	105	6	4			
76	110	6	4			
80	115	6	4			
90	130	6	4			
100	145	6	4			